



NOTE:
 Metal Finish: Brushed Nickel Finish
 Direction of Brush: Left to Right.
 Pierre to drill same size as previous valve openings.